


**MODEL NO: BTS-61 MK2**  
**BLUETOOTH SPEAKER**  
Manual (English)

**Specification**

Bluetooth: V2.0  
Transmission distance: up to 10 meters  
Output power: 3W\*2  
Frequency response: 80Hz-19kHz  
Input sensitivity: 800mV 1kHz  
Signal noise ratio: >=85dB  
Degree of distortion: =<0.6% PO=2W  
Input voltage: DC 5V 200-500mAh  
Rechargeable battery: 5C battery 400mAh  
Charging time: about 2 hours  
Playing time: about 1.5 hours

**Function Instruction**



1. Volume+ /Next, press & hold for Volume+, quick press for Next.
2. Play/Pause & Call function, press & hold for Bluetooth ON/OFF.
3. Volume- /Previous, press & hold for Volume-, quick press for Previous.
4. Bluetooth / FM radio /AUX IN.
5. Power switch: ON/OFF.
6. Charges via pc connection.
7. AUX IN.
8. External rechargeable battery.

**Operation Instruction**

1. Turn on ON/OFF to ON to start work.
2. Press "MODE" button to change between Bluetooth, FM radio, AUX IN.  
Turn on first mode is BT Mode, Press "MODE" one time is FM radio, FM mode gives instant music or white noise. Press "MODE" again is Aux in, the blue light will blink quickly.
3. When it is BT mode, it gives a beep, Bluetooth function is available for device pairing. Turn on the Bluetooth function on mobile phone find the pairing name "BTS-61" after 5 seconds, there is beep heard to be connected. You can start to play music once the pairing is done.
4. In FM radio mode, press "play / pause", it will full channel automatic, push Vol- and vol+ to change preset channels afterwards (before change into FM mode you can insert the AUX cable as the outside antenna to get better signals).
5. Press Volume-/Next & Volume+/Previous at the same time, it is switch off Previous Bluetooth.

ENG-1

6. When Charging, the light is red, when fully charged, the red light will turn off.

**Warning**

The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.  
ALL RIGHTS RESERVED, COPYRIGHT DENVER ELECTRONICS A/S

**DENVER**  
www.denver-electronics.com



Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislation and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households.

Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S, declares that this product (BTS-61 MK2) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of conformity may be obtained at :

Inter Sales A/S  
Stavneagervej 22, DK-8250 Egaa, Denmark

Imported by:  
DENVER ELECTRONICS A/S  
Stavneagervej 22, DK-8250 Egaa, Denmark  
www.facebook.com/denverelectronics

ENG-2